# On-The-Fly (OTF)Programmer — Quick Start Guide

#### Range Control

Use the Speed Dial to Control your Range. The lower the speed setting the further your golf car will drive. The Controller automatically reconfigures to run more efficiently at lower speeds. This can double your range.

## **Adjust Speed**

Use this dial to set your speed limit based on driving conditions

# Regenerative Braking

Control Regenerative Braking for Safety and Efficiency (Dial up or down depending on driving conditions)




### Acceleration

Adjust how fast your vehicle Accelerates depending on driver preference

#### Status LED

Provides Diagnostic Feedback to the driver



The Navitas Controllers are designed to work with both Series and Shunt Motor Systems – OTF Required (instructions are located in the owners manual)

# **Key Lock**

Lock and Unlock your settings. This disables the dials until the OTF is unlocked (ideal way to control the behavior of the golf cart based on owner preferences)



